



Pent Shed Assembly Manual

Pressure Treated Tanalised Timber for Longer Lasting Life!

Ready To Build - 4ft Range

Total Sheds
Unit 1 Park Lane,
West Bromwich, B21 8LE
Tel: 01902 636 529
Email: info@totalsheds.co.uk

Version 1.4

Thank you for purchasing your Total Shed.

All of our sheds are made from only the finest selected timber which are (Tanalised), specially pressure treated for a longer and lasting durable life span to the elements.

Each shed is carefully packed and delivered on a pallet ready to be assembled.

**FEATURES NEW FLEXIBLE,
INTER-CHANGEABLE DESIGN
FOR YOUR INDIVIDUAL STYLE.**

2 Persons Recommended for Assembling Shed

Tools Required:



DRILL DRIVER



HAMMER



HAND SAW



STANLEY KNIFE

PLEASE NOTE: Use extreme caution when using any tools. Always wear safety gear where necessary. It is advisable that at least 2 or more persons assemble the shed for health and safety purposes. We are not responsible for any injuries caused whilst assembling this shed.



Ready to Build Shed



**DELIVERED FLAT PACKED IN
EASY TO INSTALL SECTIONS**

Featured Build of the Pent 12x4ft Shed
Includes 4x4ft to 20x4ft Instructions

www.totalsheds.co.uk

© Sheds (Midlands) Limited 2021

Unpacking your Parts

Unpack all of the components and check that you have all the parts required. Please use the checklist on previous page.


Carefully dispose of the delivery pallet and any excess timber.

Advisable: The underside of the floor must be treated with a quality wood preserver.

SET THE SHED FOUNDATION



This Manuals Diagrams are based on the **12ft x 4ft Pent Shed**



Recommended: Paint shed in an oil based treatment to prevent water ingress into the timber. Also silicon your windows (*Must silicon inside & outside*) to prevent rain water seeping through the gaps between glass and the timber.




SHED FLOOR: Setting Shed Base

PLEASE NOTE: All Shed Floors have the 4ft x 4ft Floor on the Left.

1a. Place the Floor panels with the Frame work pointing forwards (as shown in below) then screw together using screws provided at the end of the bearer points.

1b. Check that all floor sections are securely attached and in a straight line to avoid any problems later on the build stage.

Use a Spirit Level for accuracy



● = Drill Points using screws provided as shown

1c. Secure the floor sections together by screwing the floor bearers at each end where they meet as shown in diagram 1c.



STEP • 2

IMPORTANT

All Sheds With 3 or More Floor Pannels have the smallest Floor Panel on the End.

As shown on this diagram.



FLOOR & BLOCK ENDS

Add the Floor Block Ends (Heavy Duty Posts)

2a. In your kit you should find 2x 4ft blocks. These will act as your floor block.

2b. Fix together by screwing the Floor Blocks at each end as shown. Use the screws provided and make sure the ends are fixed securely. 2 screws on each Floor Block will suffice. **(Repeat for other side)**



● = Drill Points using screws provided as shown



STEP • 3

4ft LEFT SIDE PANEL

Place first panel againts far Left of shed floor as shown.

(4ft wide blank panel)




4FT RIGHT SIDE PANEL

3a. Place the 4ft Blank Panel against the far side of the shed floor. Make sure the panel stands firmly on the Heavy Duty Post (Floor Block).

3b. Now prepare the 4ft Blank Panel in order to create an 'L' shape in the corner with the two panels.

3c. DO NOT fix the panels at this stage to the floor. This is because you need to leave room for adjustments in the final stages of the shed build.



● = Drill Points using screws provided as shown


STEP • 4

REAR PANEL

Fix 4ft Wide Blank Sections. Create a Corner for Balance.



REAR PANEL



4a. Place a 4ft Blank Panel side as shown below. Repeat this step for all larger Sheds. Please use reference on left for additional sections required according to your shed size.

4b. Screw the Blank Panel alongside the framework as shown in Diagram 4b.

INFORMATION
Not all Summer Sheds will have the same panel arrangement. Please Ensure that the 4ft Panels are central for all builds.



4b



x3
4.0 x 70mm
Per Panel Edge

● = Drill Points using screws provided as shown

STEP • 5


REAR PANEL

Place panel againsts far the back of shed floor as shown.
(4ft wide Blank Panel)



4ft REAR PANEL

5a. Place the 4ft Blank Panel side against the corner of the back 4ft floor as shown making sure the panel is sitting firmly on the shed floor and the side meeting the framework of the back 4ft Blank Panel.



5b. Fix the panels together with screws as shown in diagram. You may require some supports to keep the frame upright whilst building longer sheds.



x3
4.0 x 70mm
Per Panel Edge

● = Drill Points using screws provided as shown

STEP • 6

4ft RIGHT SIDE PANEL

Attach 4ft Blank Section to the Right Side Wall




4ft RIGHT SIDE PANEL

6a. Place the 4ft **Blank Panel** at the far **RIGHT** of the shed, connecting it with the rear sections. (Same placement as the right side 4ft panel just on the other side).



● = Drill Points using screws provided as shown

DO NOT screw the standing panels down to the floor just yet. Leave room for adjustments when the final frame is fitted.



STEP • 7

FRONT DOOR PANEL

Attach Door Front Panel (4ft Door Panel)



FRONT DOOR PANEL

7a. Now place the 4ft **Door Panel** as shown. Fix together with screws to the Left side panel framework (The side that comes in contact with the 4ft **Blank Panel**).



● = Drill Points using screws provided as shown



STEP • 8

FRONT WINDOW PANEL

Attach First Front Panel
(4ft Window Panel)



4ft FRONT WINDOW PANEL

8a. Start back from the Right side placing the 4ft Window Panel as shown. Fix together with screws to the right side panel framework.

DO NOT screw the standing panels down to the floor just yet. Leave room for adjustments when the final frame is fitted.



● = Drill Points using screws provided as shown

x3
4.0 x 70mm
Per Window Panel

STEP • 9


FRONT WINDOW PANEL

Attach Front Panel
(4ft Window Panel)



4ft FRONT WINDOW PANEL

9a. Repeat the previous stage until all Window Panels have been secured in place. Once all of the Wall panels have been secured, you can now screw the frame down to the base. Take time to ensure that the walls are square.



● = Drill Points using screws provided as shown

x3
4.0 x 70mm
Per Window Panel

STEP • 10

SIDE PENT ANGLE TOPS

Now attach all the Side Tops of Pent Shed End Panels. (Over the top of both side panels).



SIDE PENT ANGE TOPS

10a. Now place the 4ft Slope on top of the Blank Panels and use two 70mm screws to secure them together, making sure that they are in line.

10b. Once the Pent Angle Top has been constructed, use the screws to secure the Angle Tops to the sides of the Shed.



● = Drill Points using screws provided as shown

x2
4.0 x 70mm
Per Angle Top

STEP • 11


PENT FRONT TOPS

Place the front tops of shed.



PENT FRONT TOPS

11a. Place the Pent Front Top sections in place. Adjust the panels so that the tongue & groove are fixed together in place correctly. Use a hammer to lightly tap in to the grooves to create a perfect fit.



● = Drill Points using screws provided as shown

11b. Attach the sections down by screwing through the inner framework of both panels.

x2
4.0 x 70mm
Per Front Top

STEP • 12

PENT ROOF PANELS

Place First roof section.
Repeat for all Roof Panels
(2ft, 3ft, 4ft)



PENT ROOF PANELS

12a. Place the 4ft Roof Panel in place. Repeat this stage for models as shown below. 4ft Roof Panel will always be on the Left. Repeat until all Roof A Panels are fixed in place.



● = Drill Points using screws provided as shown



x4
4.0 x 70mm
Per Roof Panel

STEP • 13

SIDE & CORNER STRIPS

Hide the panel edges.
Cover the framework & seams.



SIDE & CORNER STRIPS

13a. Use all the Side/Corner Strips to finish off the shed, by covering any exposed framework and the panel joining seams.

13b. Use a 3mm Drill bit to prevent the wood from splitting. Use the 70mm Screws to secure these Strips to place. it will take 3x screws to properly secure the Strips to the Shed.

INFORMATION

The Corner Strips cover all panel edges. Remember to attach these to the exterior back panels too.



● = Drill Points using screws provided as shown



x3
4.0 x 70mm
Per Corner Strip

CUTTING THE ROOF FELT

Use the felt table to cut your felt to the correct size



CUTTING THE ROOF FELT

14a. Use the Stanley knife to cut your felt into the correct size. Using the table below, find the Build size that you have and cut your felt down to achieve the size that you will need.

Example:

Pent Shed 12ft x 4ft

The 12 by 4 needs 2 sheets of felt. All at 13ft each.



		Build Depth				
		4ft (x2)	5ft (x3)	6ft (x3)	7ft (x4)	8ft (x5)
Build Length	4 ft	5ft	5ft	5ft	5ft	5ft
	5 ft	6ft	6ft	6ft	6ft	6ft
	6 ft	7ft	7ft	7ft	7ft	7ft
	7 ft	8ft	8ft	8ft	8ft	8ft
	8 ft	9ft	9ft	9ft	9ft	9ft
	9 ft	10ft	10ft	10ft	10ft	10ft
	10 ft	11ft	11ft	11ft	11ft	11ft
	11 ft	12ft	12ft	12ft	12ft	12ft
	12 ft	13ft	13ft	13ft	13ft	13ft
	13 ft	14ft	14ft	14ft	14ft	14ft
	14 ft	15ft	15ft	15ft	15ft	15ft
	15 ft	16ft	16ft	16ft	16ft	16ft
	16 ft	17ft	17ft	17ft	17ft	17ft
17 ft	18ft	18ft	18ft	18ft	18ft	
18 ft	19ft	19ft	19ft	19ft	19ft	
19 ft	20ft	20ft	20ft	20ft	20ft	
20 ft	21ft	21ft	21ft	21ft	21ft	

ATTACH THE ROOF FELT

Use the felt lengths provided.



ROOF FELT




15a. Apply the roof felt as shown. Apply lower levels first to create correct rain run off positions.



15b. Using a hammer, tack down the felt with the tacks provided in a neat fashion.



15c. Trim down excess felt with a stanley knife. Remember to overlay the 1st felt to avoid rain leaks.



15d. Tuck and fold edges neatly and tack in place to hide any loose edges. Check that all areas are covered and there are no holes to avoid any rain water getting through your felt roof.



TACKS PROVIDED

ATTACH FELT STRIPS

Create the Final Roof Edges. Final steps finishing off the roof.



FELT STRIPS

16a. Using the felt strips provided cover the edges of the roofs and ends of the roof felt. You will need to measure these and saw to fit to your requirements and create the perfect roof finish as shown below.

16b. Drill in the felt strips as shown on front and back of the shed to finish the roof off. Use the framework of the roof blocks to screw the felt strips down to. The felt strips will give your shed a neat finish for the roof and hide any overhang areas of the roof felt.



● = Drill Points using screws provided as shown

NOTE:
Location of the Felt Strips

16c. Felt Strips must be same height as roofing felt to allow rain water to run off. See Diagram on the right.



DIAMOND CAPS

Add the Finishing Touch. (Optional)



Total Sheds
Unit 1 Park Lane,
West Bromwich, B21 8LE
Tel: 01902 636 529
Email: info@totalsheds.co.uk

FINISHED!



Congratulations

Timber is a naturally grown product and may shrink and warp when dried out, timber is a porous material which can absorb water. Although all of our buildings come pressure treated we strongly advise the building is re-treated with an oil/spirit based treatment inside and out to make the timber water repellent and to preserve the quality and life of the product.